

Anchor and ScottLabs Yeast Trial on Merlot (2014)

Blenheim Vineyards

Kirsty Harmon

Purpose: Assess fermentation kinetics and sensory attributes of several Anchor yeast strains on Merlot.

Methods: Identically sourced 2014 Merlot was harvested, destemmed but not crushed, and separated equally into 4 macrobins. Each bin is inoculated at 95g/bin with EC-1118 PDM (Scott Lab), CRVP (Scott Lab), NT50 (Anchor), and NT202 (Anchor) respectively. Each bin was treated identically through AF, pressed identically, and racked to identical barrels (Seguin Moreau MT American Oak 2009). Each barrel was inoculated with ML Silver (1g/barrel). 4.5g/hL SO₂ added upon completion of MLF. Results:

Results:


CRVP exhibited the fastest fermentation kinetics but produced the highest volatile acidity. EC1118 PDM produced the highest ethanol and lowest volatile acidity.

Figure 1:


Yeast	pH	Alcohol	Acetic acid
PDM	3.71	13.4	0.15
NT 50	3.74	12.9	0.19
NT202	3.74	13.2	0.23
CRVP	3.83	12.8	0.27

Figure 2:


EC1118




NT202




NT50



CRVP





Full Methodology

Merlot - Seaview

9/5/201

picked: **4** pound
12043 s

kept cold in reefer O/N

9/6/2014

destemmed but not
crushed
4 Macrobins - 60 lugs each
approx 475 liters

33 g KMBS added to each
bin
35 mg/L
equivalent

Chemistry 20.8 BRIX
 3.47 pH

9/7/2014 95g yeast to each of 4 macrobins (20 g/hL)

9/10/2014 added 15 lbs of sugar(14.5g/L) and 95g (20g/hL)

9/18/2014 pressed each bin individually - Program 1 europress

9/19/2014

	pH	BRIX	Malic
PDM	3.69	-1.6	2.24
NT 50	3.60	-1.4	1.79
NT202	3.59	-0.9	1.93
CRVP	3.59	-1.6	1.65

9/23/2014 - Racked to 4 identical barrels Seguin Moreau, Medium Toast, American Oak, 2009
added 1 g/ barrel ML Silver

10/16/201

4 MLF done on NT50, NT202, CRVP. Added 20 g KMBS (44mg/L) to each barrel

10/23/201

4 MLF done on PDM. Added 20 g KMBS (44mg/L) to each barrel

12/02/14

	pH	free SO2
PDM		
NT 50	3.73	24
NT202	3.73	22
CRVP	3.70	21

2/20/2014

	pH	Alcohol	Acetic acid
PDM	3.71	13.4	0.15
NT 50	3.74	12.9	0.19
NT202	3.74	13.2	0.23
CRVP	3.83	12.8	0.27